



RS-659 RS-12

RS-8

REMOVE FOR MAG. CLEARANCE AS NEEDED

5 1/4"

THRUST LINE CENTER (HUB)

TOP LONGERON

TOP PLY.

FIREWALL

SIDE PLY. NOT SHOWN

RS-201

SIDE VIEW

1/4" = 1"

COUNTERSUNK AREA FOR ANGLE MOUNT BOLTS (10) REQ.

RS-10

RS-660

RS-10 WEDGE

RS-201 AL. ANGLE

FRONT VIEW

FIREWALL PLY. NOT SHOWN 1" = 1"

HYPOTHETICAL LOCATIONS FOR MOTOR MOUNT HARD POINTS (7 SHOWN)

FIREWALL

RS-10

RS-12 (TOP)

RS-201

1/8 PLY.

2 1/2 degree WEDGE (PINE) RS-10-CUT TO FIT.

RS-8 LONGERON (TOP)

SECTION A-A

1" = 1"

RS-11

RS-8

RS-659

2-93  
 PROPOSED MOUNT HARDPOINTS FOR MOSLER ENGINE